

## FRONT CAB CURTAIN FITTING INSTRUCTIONS



### Step 1:

First, with some help pull the centre of the curtain as you can see in the photo above to the corners of the windscreen. Then flip down the sun visors over the curtains to hold them in place between the screen and visor.



### Step 2:

Pull the curtain as shown in the photo. On each side of the front windscreen you will see metal poppers pressed in the curtain, pull gently and position under the place where you think is suitable and mark with a pencil ready for drilling on both sides of the windscreen.



### Step 3:

Attach the popper using a rivet to the roof lining securely.



### Step 4:

You are now ready to attach your Van-X Front Curtain, push the poppers together, and then pull the curtains back towards about the seatbelt on each side by following the next step.





### Step 5:

The final step, the poppers are attached the same as at the front corners on steps 2 & 3.

Then you will have another popper about 20 inches below this one.



### Congratulations!

You've fitted the Van-X Front Cab Curtains. If you have had any issues in fitting or any further questions, please don't hesitate to give us a call on 01782 280 888.